

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

FUN4304 Wailing Banshee



Please follow the step by step guide and enjoy your Wailing Banshee!

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

⚠ WARNING

- This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.
1. Please use the adapter supplied by manufacturer.
 2. Please assemble item according to instructions. Connect all wires according to matching color.
 3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard.
 4. Keep all away from the adapter, as it heats up during operation.


PARTS LIST

- A. Base x 1
 - B. Lower Poles x 2
 - C. Upper Poles x 2
 - D. Hip Frame x 1
 - E. Costume x 1
 - F. Body Frame x 1
 - G. Left Arm x 1
 - H. Right Arm x 1
 - I. Head x 1
 - J. Back Frame x 1
 - K. Adapter (Included) x 1
- Input: 100 - 240VAC 50/60Hz
Output: 5.9V 1.5A



BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT CUSTOMER SERVICE AT CUSTOMERSERVICE@SVIUS.COM, OR BY PHONE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921.


Assembly Instructions:



STEP 1
Note: Throughout the instructions, left and right are relative to the character.
Insert both (B) Lower Poles to the (A) Base and secure by using the available quick connect push button and pre-drilled hole as shown in Figure 1.
Then set the struts from the (A) Base into the housings available on the (B) Lower Poles as shown in Figure 2.
Connect both (C) Upper Poles to the (B) Lower Poles using the available quick connect push button and pre drilled holes as shown in Figure 3.



STEP 2
Insert the (D) Hip Frame to the (C) Lower Poles by using the available quick connect push button and pre drilled holes as shown in Figure 1.
Slide the (E) Costume over the assemble frame as shown in Figure 2.
Then connect the (F) Upper Body Frame to the (D) Hip Frame using the available quick connect push button and pre drilled hole as shown in Figure 3.
Now, plug the Adapter into the input receiving jack marked "DC 5.9V" on the Function Control Box and route the Power Adapter down and out the bottom of the item.




OPTIONAL: If you choose to use the Step Here Try-Me Activation Pad, plug the connector into the input receiving jack marked "TRY ME" on the Function Control box and route the Step Here Pad down and out the bottom, then set the Step Here Pad in front of the character.
Note: Do not plug the Adapter into power outlet until item assembly is completed.



STEP 3

Bring the (E) Costume up over the (F) Body Frame as shown in Figure 1. Slide the (G) Left Arm up the left sleeve of the (E) Costume as shown in Figure 2, and insert the forked hook of the (G) Left Arm into the forked hook housing available on the left side of the (D) Body Frame as shown in Figure 3. Then secure the sleeve of the (E) Costume by using the hook and loop closure available on the hand of the (G) Left Arm as shown in Figure 4.



STEP 4

Slide the (H) Right Arm up the right sleeve of the (E) Costume as shown in Figure 2, and insert the forked hook of the (H) Right Arm into the forked hook housing available on the right side of the (D) Body Frame as shown in Figure 2. Then secure the sleeve of the (E) Costume by using the hook and loop closure available on the hand of the (H) Right Arm as shown in Figure 3.



STEP 5

Slide the forked hook housing available on (I) Head into the forked hook available on the top of the (D) Body Frame as shown in Figure 1. Attach cables from the Function Control Box to their corresponding cables by color as shown in Figure 2. Secure sensor available on the Function Control Box into the sensor hole of the (E) Costume by using the hook and loop closure as shown in Figure 3. Insert the forked hook available on the (J) Spinal Frame to the forked hook housing available on the (D) Body Frame as shown in Figure 4.



STEP 6

Close the back of the (D) Costume by using the available hook and loop closures as shown in Figure 1. Secure collar by using the hook and loop closure available on the collar and the neck of the (E) Costume and (I) Head as shown in Figure 2. Your Wailing Banshee is now fully assembled. Plug in and turn on to let the fun begin!

OPERATION INSTRUCTIONS:

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (F) Body Frame, as desired.

2. Settings:

Sensor /Détecteur	This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.
○	This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for one audio cycle with each Try Me activation.
I	This switch mode will continually operate the lights, sound, and animation of the item.
	Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off .

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

Seasonal Visions International, Emeryville, CA 94608, USA, Tel: (855) 428-3921

