

LIST OF ACCESSORIES

A: Chest piece

B: upper part of body


C: pant

D: shoes

E: sound box



1: The light sensor connector buckle is fastened with the sound box connector buckle



2. Velcro for both chest piece and clothing



3. Velcro for both lower chest piece and pant



4. Velcro for both lower chest piece and pant



Finished product display



switch



sound box with three AA 1.5V batteries

