




7.55 FT LIFE-SIZE ANIMATED DEMOGORGON STRANGER THINGS-NETFLIX

Thank you for purchasing the Life Size Animated Demogorgon! Below you'll find assembly instructions and other information to get maximum enjoyment from your purchase.

Please keep these directions for future reference as they contain important information.

PACKAGE CONTENTS

- | | | | |
|--------------------|--------------------|-------------------------|---------------------------------|
| A. Base | I. Lower right leg | Q. Head | X. UNLABELED ACCESSORIES |
| B. Support pole 1 | J. Upper right leg | R. Upper left arm | Includes: Ropes (4 PC), Spiral |
| C. Support pole 2 | K. Left foot | S. Upper right arm | Stakes (4 PC), Eye Bolts (2 PC) |
| D. Support pole 3 | L. Lower left leg | T. Lower arm/right hand | |
| E. Support pole 4 | M. Upper left leg | U. Lower arm/left hand | |
| F. Extension poles | N. Hip front | V. Try Me button | |
| G. Waist frame | O. Hip back | W. Power adaptor | |
| H. Right foot | P. Upper body | | |



PREPARATION

Estimated Assembly Time: 15 - 20 minutes

Before assembling the product, carefully remove all parts from the box and lay out on a flat surface.

Make sure all parts are present. Compare parts with package contents list.

If any part is missing or damaged, do not attempt to assemble, install or operate the product.

Read through directions before assembling.


ASSEMBLY INSTRUCTIONS



1. Place the support poles (B,C) onto the base (A). Secure by aligning the quick-connect push button into the pre-drilled holes and snap into place.




2. Thread the feet (H,K) over the support poles.



3. Thread the lower legs (I,L) over the support poles and place atop feet.



4. Attach the remaining support poles (D,E) to support poles (B,C) by aligning and snapping into the quick-connect push buttons.



5. Thread the upper legs (J,M) over the support poles (D,E) atop the lower legs.



6. Attach the waist frame (G) to support poles (D,E) and snap into place.

ASSEMBLY INSTRUCTIONS



7. Connect the hips (N,O) over assembled legs and waist frame as shown.



8. Assemble the upper body (P), head (Q) and arms (R,S) before attaching to main figure. First, insert the head into the corresponding receptacle on top of the neck as shown. Turn the head in a counterclockwise fashion to secure and tighten it.



9. Attach the arms (R,S) into the corresponding receptacles on each side of the body and snap into place as shown.



10. Attach the assembled upper body to the assembled lower body and snap into place as shown.



11. Open the lid on the back of Upper body, connect power adaptor (W) and Try Me button (V) to the function box.



12. Attach the lower arms/hands (T,U) and tighten them into place by rotating clockwise on each corresponding upper arm.


ASSEMBLY INSTRUCTIONS



For additional stability, attach the extension poles (F) to the corners of the base (A) as shown. Align with corresponding quick-connect push buttons in the pre-drilled holes and snap into place.



Secure figure to ground with the included spiral stakes and ropes (X). Tie two ropes to one eye bolt. Tie the other ends to two spiral stakes. Push stakes into the ground so rope is taut but not too tight. Repeat on the other side, placing the four ropes and stakes evenly around the assembled figure and base to protect from strong winds.




ANIMATION FUNCTIONALITY

The Life-Size Animated Demogorgon has two operational settings on the main control box located inside the upper body, open the lid on the back of upper body to see the main control box :

ON/TRY ME: Switch to "ON" position to activate the figure and sound effects with the "TRY ME" push button.

SENSOR: Switch to "SENSOR" position to turn on sound and motion activation. Sounds and light disruptions will activate the figure for one audio-cycle per activation.

WARNING
This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children. This product is intended for people ages 13 and up.



Try me /Essaie moi /Pruzbame

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

On (Try ME) /Sensor
On (Essaie moi) / D3tecteul
On (Pruzbame) / Sensor

Este dispositivo cumple con la Sección 15 de las Normas FCC. La operación queda sujeta a las siguientes dos condiciones: 1) este dispositivo no debe provocar interferencia dañina, y 2) este dispositivo debe aceptar toda interferencia recibida incluyendo la interferencia que podría causar una operación no deseada.

DC 5.9V

WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause interference
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits or a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©2025 GEMMY INDUSTRIES CORP.
117 WRANGLER DRIVE, SUITE 100
COPPELL, TX 75019 U.S.A.
1 (800) 274-6717
MADE IN CHINA
PRINTED IN CHINA



[gemmy.com/product-assembly/](https://www.gemmy.com/product-assembly/)



THESE INSTRUCTIONS APPLY
TO THE FOLLOWING ITEM NUMBER
553230