

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

FUN96451 Area 51 Roswell Alien



Please follow the Step by Step Guide and enjoy your Area 51 Roswell Alien!

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

- 1. Please use the adapter supplied by manufacturer.
- 2. Please assemble item according to instructions. Connect all wires according to matching color.
- 3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard.
- 4. Keep all away from the adapter, as it heats up during operation.


PARTS LIST

- A. Base x 1
 - B. Left Support Pole x 1
 - C. Right Support Pole x 1
 - D. Left Leg x 1
 - E. Right Leg x 1
 - F. Body x 1
 - G. Left Leg Cap x 1
 - H. Right Leg Cap x 1
 - I. Left Arm x 1
 - J. Right Arm x 1
 - K. Head x 1
 - L. Adapter x 1
- Input: 100 - 240VAC 50/60Hz
Output: 5.9V 2.0A




BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT CUSTOMER SERVICE AT CUSTOMERSERVICE@SVICHINA.COM


Assembly Instructions:




STEP 1
Note: Throughout the instructions, left and right is at the character's point of view. Attach the (B) Left Support Pole and the (C) Right Support Pole to the poles on the (A) Base using the quick connect push buttons and pre-drilled holes as shown in Figure 1. Slide the (D) Left Leg and the (E) Right Leg down the assembled poles as shown in Figure 2.



STEP 2
Attach the (F) Body to the Left and Right Support Poles using the quick connect push button and pre-drilled hole on the (C) Right Support Pole as shown in Figure 1.



STEP 3
Place and secure the (G) Left Leg Cap and the (H) Right Leg Cap at the back of the legs as shown in Figure 1. Attach the (I) Left Arm to the (F) Body by aligning and sliding the hex pole from the left side of the (F) Body to the hole on top of the (I) Left Arm and using a Phillips screwdriver tighten the screw located on the shoulder part of the (I) Left Arm as shown in Figure 2. Note: Do not over tighten the screw.



STEP 4
Attach the (J) Right Arm to the (F) Body by aligning and sliding the hex pole from the right side of the (F) Body to the hole on top of the (J) Right Arm and using a Phillips screwdriver tighten the screw located on the shoulder part of the (J) Right Arm as shown in Figure 1. Note: Do not over tighten the screw, To attach the (K) Head to the (F) Body, align and slide down the hole at the bottom of the (K) Head to the peg at the top of the (F) Body and tighten the screw at the nape part of the (K) Head using a Phillips screwdriver as shown in Figure 2. Do not over tighten screw.




STEP 5
Your Area 51 Roswell Alien is now fully assembled. Plug in or install batteries and turn on to let the fun begin!

OPERATION INSTRUCTIONS:

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (F) Body, as desired.

○	OFF/TRY ME - This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for one activity cycle with each Try Me activation.
I	ON - This switch mode will continually operate the lights, sound and animation of the item.
Sensor /Détecteur	This switch mode will activate lights, sound and animation when the light sensor is activated and will operate for one activity cycle with each activation. The light sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.
⌚	VOLUME - Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off.



The Area 51 Roswell Alien can either be powered by an adapter or batteries. Plug the power adapter into a standard power outlet or insert 4 x 1.5V C batteries into the battery box.

NOTE: When using the adapter while batteries are in the product, the power will be sourced from the adapter only. However, it is advised to remove the batteries from the product when using the adapter.

BATTERY WARNING:

Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries. Do not mix old and new batteries. Rechargeable batteries to be removed from the product before being charged. Only batteries of the same or equivalent type as recommended are to be used. Rechargeable batteries are only to be charged under adult supervision. Non-rechargeable batteries are not to be recharged. Batteries are to be inserted with the correct polarity. Remove batteries if consumed or if product is to be left unused for a long time. The supply terminals are not to be short-circuited. Dispose of batteries safely. DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK

NOTE: Requires 4 x 1.5V C batteries (Not Included)

* You will need a small Phillips head screwdriver (Not included).

Locate the battery compartment on the product. Remove the battery compartment cover by using a small Phillips head screwdriver to unscrew the screw. After removing or installing the batteries, place the battery compartment cover into position, and secure the battery cover. If Area 51 Roswell Alien is being stored while not in use, please remove battery in Remote Control.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

Seasonal Visions International, Berkeley, CA 94710, CUSTOMERSERVICE@SVICHINA.COM

IMPORTANT SAFETY INSTRUCTIONS -SAVE THESE INSTRUCTIONS

DANGER! TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK READ AND FOLLOW ALL SAFETY INSTRUCTIONS:

Read and follow all instructions that are on the product or provided with the product. For a cord-connected or direct plug-in power unit, do not use an extension cord. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction. For a cord-connected or direct plug-in power unit, do not install or use within 10 feet of a pool.

WARNING: Risk of electric shock. When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.

WARNING: Risk of Fire. Installation involves special wiring methods to run wiring through a building structure. Consult qualified electrician.